

ASSEMBLY INSTRUCTION

Page 1

MODEL : IFN - AF 5088 (FORESTER) KING SINGLE BED - Wooden Slat

Before you begin, please follow Assembly Instruction carefully. Follow them step by step.

STEP 1

(A) M6 X 100MM JCBC SCREW - 4 PCS

(B) M4 ALLEN KEY (BALL TYPE) - 1 PC

(D) WOOD DOWEL M10 X 40MM - 8 PCS

(E) BARREL NUTS M6 X 15MM - 4 PCS

STEP 2

(A) M6 X 100MM JCBC SCREW - 4 PCS

(B) M4 ALLEN KEY (BALL TYPE) - 1 PC

(D) WOOD DOWEL M10 X 40MM - 8 PCS

(E) BARREL NUTS M6 X 15MM - 4 PCS

STEP 3

(A) M6 X 100MM JCBC SCREW - 8 PCS

(B) M4 ALLEN KEY (BALL TYPE) - 1 PC

(D) WOOD DOWEL M10 X 40MM - 4 PCS

(E) BARREL NUTS M6 X 15MM - 8 PCS

ASSEMBLY INSTRUCTION

Page 2

MODEL : IFN - AF 5088 (FORESTER) KING SINGLE BED - Wooden Slat

Before you begin, please follow Assembly Instruction carefully. Follow them step by step.

STEP 4

REQUIRED ASSEMBLY TOOLS : POZI SCREWDRIVER - 1PC

(C) M4 X 32MM CSK SCREW - 12 PCS

REMARK : ATTACH PART 6 USING (C) SCREW AND POZI SCREWDRIVER AS SHOWN.

FULL SETUP

PART LIST

1) HEAD POST X 2 PCS	4) FOOTBOARD PANEL X 1 PC
2) FOOT POST X 2 PCS	5) WOODEN SIDE RAIL X 2 PCS
3) HEADBOARD PANEL X 1 PC	6) WOODEN SLATS X 14 PCS

HARDWARE LIST

(A) M6 X 100MM JCBC SCREW - 16 PCS	(D) WOOD DOWEL M10 X 40MM - 20 PCS
(B) M4 ALLEN LEY (BALL TYPE) X 1 PC	(E) BARREL NUT M6 X 15MM - 16 PCS
(C) M4 X 32MM CSK SCREW - 12 PCS	