



# Printer Stand

UFG02PS01/UBK02PS01

Method 1



Method 2



## **General Guidelines**





1. Please read the following instruction carefully and use the product accordingly.
2. Please keep this manual and hand it over when you transfer the product.
3. This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.

## **Warnings**


1. Children are not allowed to assemble the product. During assembly, keep small parts out of the reach of children as they may be fatal if swallowed or inhaled.
2. Keep plastic packing bags out of reach of children to avoid any potential danger, such as suffocation.
3. Avoid sharp objects and corrosive chemicals to prevent damage to the product or the user.
4. Please do not use the product if there is/are defective and/or missing part/s, as this can result in damage or injury.

## **Notes**


1. The item is only intended to be used indoors. Personal injury and/or damage to the product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The product must be assembled and used in accordance with the provisions of the manual. The seller does not assume any responsibility or liability with respect to any damage caused by incorrect assembly or improper use.
2. Do not place it in a damp environment for extended periods of time to prevent mildew.
3. During assembly, first loosely align all screws with the corresponding pre-drilled holes and then tighten the screws one by one.
4. Periodically inspect screw tightness while the product is in use. If necessary, re-tighten to ensure structural integrity.



1





2




- Two assembly methods can be chosen according to the needs.

Method 1

Assembly of castors.




Method 1  
Assembly of castors.



- Two assembly methods can be chosen according to the needs.

Method 2

Assembly of adjustable feet.



Method 2  
Assembly of adjustable feet.

