


**MH-WC (WS5830)**  
**CAMILLE/CORA/COURTNEY DINING CHAIR IN K/D (PAIRS)**



**GENERAL**

1. PLEASE READ this sheet prior to assembly to familiarise yourself with each stages of construction.
2. Please retain all packaging until you are certain that you have all the necessary parts for the assembly.
3. This assembly requires two adults; assemble this unit on a flat surface and clean cloth in the room that it is intended for.
4. CAUTION: There are small components used in the construction of this unit. Keep the fittings out of the reach of children whilst assembling your unit to avoid danger.
5. For care: Soft and damp microfiber cloth will be adequate when cleaning the surface of furniture. Please also take care to not put sharp objects such as keys on the surface to ensure you preserve the product surface.
6. Please do not fully tighten the screw unless you have completely assemble the product.
7. Please keep this assembly instruction for future reference, and check and retighten the bolts/screws on a regular basis.



20 minutes required



This assembly requires  
minimum TWO adults



Never push or drag the  
chair to avoid any  
potential damage on the  
chair leg and floor



**WARNING:**

DO NOT STAND ON THE CHAIR, DO NOT USE THIS CHAIR AS A STEP LADDER. USE THIS  
PRODUCT ONLY FOR SEATING.

DO NOT USE THIS CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE FIRMLY SECURED.

AT LEAST EVERY 4 MONTHS, CHECK ALL BOLTS, SCREWS AND KNOBS TO BE SURE THEY  
ARE TIGHT.

IF PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USING THIS PRODUCT UNTIL  
YOU HAVE REPAIRED IT FULLY.

FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

PLEASE DO NOT USE KNIFE TO OPEN ANY PARTS OF THE BOX OR CHAIR



Please keep this assembly instruction for future reference

## **CARE INSTRUCTION FOR UPHOLSTERY**

Unless otherwise stated, the upholstery furniture is designed for general domestic use and must always be stored at normal room temperature as heat, moisture and cold may cause changes in the fabric characteristic of the furniture material.

### **FABRICS**


Chenille, velvet and plush can tend to get pressure marks when the fringe settles down and it becomes imprinted, so it looks worn, which is normal for this type of fabric. The fabric can also vary in several different shades depending on the light. A handheld steam cleaner may help lift any crushed pile on the velvet.

### **GENERAL CARES**

1. Always treat spots and stains immediately – it is not recommended to use spirit cleanser or detergent; we advise using a cloth moistened with mild soapy water.
2. Test clean a less visible area first before attempting to clean the main stain/spillage.
3. Use a vacuum cleaner or soft brush to remove surface dust. Non-removable covers should not be washed or dry-cleaned.
4. Avoid placing sharp objects on furniture surfaces as it can be particularly damaging to upholstered furniture.
5. To prevent possible marks / stains on the surface, do not leave any food, liquids, newspapers or other printed materials on the upholstery.
6. Avoid exposure to sunlight or placing too close to a heat source as this will cause the fabric to fade, stain or bleach.
7. The velvet may appear crushed when new, but this can be resolved by sweeping with a clothes brush or a wedge of foam, (or in rare cases, by professional steaming). Over time, the velvet may crush but this is part of the antiquing process and will not affect the durability or charm of the products.

## ASSEMBLY INSTRUCTIONS

### PART / HARDWARE LIST



#### COMPLETE ASSEMBLY

THANK YOU FOR PURCHASING THIS QUALITY PRODUCT. BE SURE TO CHECK ALL PACKING MATERIAL CAREFULLY FOR SMALL PARTS WHICH MAY HAVE COME LOOSE INSIDE THE CARTON DURING THE SHIPMENT. SEPARATE, IDENTIFY AND COUNT ALL PARTS AND METAL HARDWARE, COMPARE WITH THE PARTS LISTS BELOW TO BE SURE ALL PARTS ARE PRESENT. PLEASE FOLLOW THE ASSEMBLY INSTRUCTIONS CLOSELY. IMPROPER ASSEMBLY CAN RESULT IN PERSONAL OR PROPERTY DAMAGE.




#### PART LIST - For 02pcs dining chair

| CODE     | DESCRIPTION       | QTY.   |
|----------|-------------------|--------|
| <b>1</b> | CHAIR SEAT + BACK | 02 PCS |
| <b>2</b> | FRONT LEGS        | 04 PCS |
| <b>3</b> | REAR LEGS         | 04 PCS |

#### HARDWARE LIST- PER PACK x 2pack *(hardware put underneath the chair seat)*

| CODE     | DESCRIPTION | QTY.               |
|----------|-------------|--------------------|
| <b>A</b> |             | BOLTS - M8x45MM    |
| <b>B</b> |             | BOLTS - M8x55MM    |
| <b>C</b> |             | Flat Washer - Ø8   |
| <b>D</b> |             | Spring Washer - Ø8 |
| <b>E</b> |             | Allen Key          |

## STEP 1




**AX4**



BOLTS - M8x45MM

**CX4**






**DX4**



### Remark:

Insert the screws into the assemble holes and tighten to 50%.  
Repeat the steps until all chair legs are assembled.  
Adjust the balance of the chair legs until all parts are aligned.

## STEP 2



**BX4**



BOLTS - M8x55MM

**DX1**




**CX1**



### Remark:

Insert the screws into the assemble holes and tighten to 50%.  
Repeat the steps until all chair legs are assembled.  
Adjust the balance of the chair legs until all parts are aligned.


## STEP 3



**Remark:**

**Tighten each screw 80% by using Allen Key and place the chair on a flat surface. Adjust the legs to ensure that they are aligned correctly and stable prior to fully tightening. Please slowly tighten the screw to 100% and make the chair align.**

## STEP 4



**CAUTION: The maximum weight limit is 110kg of this dining chair.**

