



IF-BC0329

Assembly Instruction

Ax1		Ex1	
Bx1		Fx1	
Cx1		Jx8	 M6*16mm
Dx1		Hx1	

