
#### **ASSEMBLY INSTRUCTIONS**

#### Important Safety Instructions:

- Please read all instructions before beginning assembly
- Please make sure receive all the parcels to start the assembly
- For your safety and convenience, assembly by two people is recommended
- Use the parts and hardware lists to identify and separate each of the components included
- Save all packing materials until assembly is completed to avoid the accidental discarding of smaller parts or hardware




THANK YOU FOR PURCHASING

#### PARTS LIST

1 X1 2 X1 3 X2 4 X2 5 X1

6 X3 7 X1 8 X1 9 X1 10 X1


10 X1 12 X1 13 X1 14 X1 15 X1





# HARDWARE LIST


Name	Part	Qty.	Spare
А		20	1
В		20	1
С		2	1
D	8	2	1
Е		28	1
F		8	
G		2	
Н		2	
I	3/4" Bolt	4	1
J	2" Screw	7	
K	1-1/2" Screw	6	
L	9/16" Screw	8	1
М	1/2" Screw	4	1

Name	Part	Qty.	Spare
Ν	1/2" Screw	6	
0		2	
U1	E promonomore	2	
U3		2	
U4		1	
U5		1	






















# 














- -Move unit to final location.
- -Adjust drawer fronts as shown below.
- Step1--Loosen screws on back of drawer front brackets as shown.
- Step2--Position drawer front as required.
- Step3--Tighten screws while holding drawer front in position.








STEP 3.
























**U**<sub>3</sub> x1pc












- 1. Place unit in desired location.
- 2. Mark stud location on the wall, 1" below top and side of unit.
- 3. Drill 5/16"hole 2" deep at marks on the wall.
































#### Maximum weight capacities

