













	OAK with
PRODUCT NAME	RENO 3Doors Shoe Cabinet	



1. Identify the parts which make up your piece of furniture.
 2. Gather the hardware parts and count them.
 3. Have the necessary assembly tools ready.
 4. Organize a space for assembly, wall carpeting or a blanket will protect the furniture against scratches.
 5. Never force the assembling while you put the parts together. You are recommended to tighten the screws after the furniture has been used for some time.
 6. After assembling this product, it is advisable to regularly ventilate the room for a few days.
- KEEP THE ASSEMBLY INSTRUCTION. THE RELEVANT INFORMATION YOU CAN FIND ON IT WILL HELP YOU GET IN TOUCH WITH YOUR STORE IF A PART WAS TO BE MISSING.



A  x64	B  3.5x40mm x12	C  3.5x16mm x70	D1  x4 D2  x2	E  x4
F  x6	G  x4	H  x12	I  x1	J  x1




SET-UP TIME: 30 MINUTE



OUTILLAGE:
TOOLS:




NUMBER OF PERSONS: 02




screw driver or drill

1



A



x12

C




3.5x16mm
x6

F




x3

2



A



x12


3

C




3.5x16mm
x6

F




x3


A



x12



4



C



3.5x16mm
x20

G



x4

E




x4

J




x1

6




A




x8


7



8




A



x8


9



C


3.5x16mm
x24

D1




x2

D2




x2

Priority is given to using elliptical voids for positioning modulation, with circular voids being fixed last.




This screw adjusts the extent of the leaf opening, used to regulate the gap between the doors.

10



A



x12

B



3.5x40mm
x12

C




3.5x16mm
x12

F




x6



11



The installation of drawers is fixed and cannot be randomly adjusted. They cannot be used randomly. They are only used for fixing the drawer surface and are labeled



12





H



x12

13




wall stripe need fix on the main frame,
not on the back panel

C



x2

I



x1